

# VIBRATING WATCH




## Charging

- ★ Please charge fully before first use.
- . Gently pull to remove the watch face from the band to reveal the **USB contacts**.
- . Plug the watch USB which have two golden lines into your power bank, laptop or desktop computer like below photo.
- . A full charge takes about 1 hour, can last 10-35 days. After one min charging the watch will display a **blinking blue light**. if you don't see it, rotate the watch face and reinsert.



USB contacts



blinking blue light  
stable blue light  
means full charged

## Setting The Time

- . When screen is black, press the **bottom** button once to display the time.
- . Quickly hold down the **bottom** button until the hours flash, Press bottom button to increase the hours, or the top button to decrease.
- . Quickly hold down the **bottom** button until the minutes flash, Press bottom button to increase the hours, or the top button to decrease.
- . Quickly hold down the **bottom** button until 12H or 24H show, press any button to select 12 hour or 24 hour format

## Setting Alarms





- . **To set the alarm time:** Press bottom button over and over when the desired alarm time appears( for example alarm 1 time 10:00), hold down the bottom button until hours flash, press bottom button to increase the hours, or top button to decrease. hold down the bottom button until the minutes flash, press bottom button to increase, or top button to decrease.
- . **To turn the Individual alarm on/off :** After alarm minutes chosen, quickly hold down bottom button to see A1OF (or when screen is off, press bottom button over and over to see A1OF), Now press top button can switch to A1ON.
- . Continue to press the bottom button to cycle through all the next alarms, repeat above to modify.



## Setting The Timer

- . **To turn the timer on:** When screen is off, press the **top** button repeatedly to display Cdn, 1, 5, 10, 15, 20, 30, 45, 60, 90, 120, 180 min, When you reach your desired interval hold down the **top** button until "ON" appears.
- . Now press the **top** button to see time remaining, press again is current time, and again is battery level.
- . **When timer is on, all the color icons will flash and jump from one to another.**
- . **To turn the timer off:** Press any button to display the time remaining, quickly hold down the **top** button for 4 seconds until "OFF" appears.
- . **Tip: If you want to change the alarm and current time after setting the timer, first turn off the timer.**

## Basic Actions

- Check time: Press bottom button once
- Check battery level: Keep press bottom button to display (  $\frac{90}{\equiv}$  )
- Check Alarm setting: Keep press bottom button to display ALM (Alarm)
- Check Countdown timer setting: Press top button once, display Cdn (Countdown), keep press to show 1min
- Press bottom button over and over to see all the alarms, kindly note the sequence is ALM, Alarm 1 time, A1 on/off, Alarm 2 time, A2 on/off, Alarm 3 time, A3 on/off, ( the numbers is before each alarm, if you set Alarm 1 on, Alarm 2 time, the alarm 2 will not vibration).

- **Quickly turn on/off the alarm** : when you see the alarm you want to turn on/off, for example, when you see A1OF, press the top button can switch to A1ON (a clock symbol will appear  ), keep press top button to A1OF.
- **Mute Mode** : This will temporarily deactivate vibration for all alarms and timer setting. Hold both buttons together for 3 seconds until “SIL” show (a red silent icon will appear  ).
- **Vibrate Mode**: Hold both buttons for 3 seconds to reactivate vibration for all alarms and timer setting. “VIB” will show.

- **Lock Button** : Prevent accidental changes to programmed settings. when screen is off, press bottom button once to see “Time”, hold down the top button for 5 seconds in “Time” screen to lock, a pink lock icon will appear , continue to hold down the top button for 5 seconds in “Time” screen to unlock, the pink lock icon will disappear. **Lock button in timer mode**: when screen is black, press bottom button twice to see current time, hold down top button for 5 seconds to lock button, continue to hold down top button for 5 seconds can unlock.

## Notes

- You can't do any change in Lock Button mode, unlock first then change the setting.
- Only when you press the button the watch will be lit and show the time.
- The watch is waterproof in normal life, but can not be used in the swimming pool, If got wet, try to dry it with hairdryer or days later to charge .
- Alarm 1 has a longer alarm time-60 seconds-to be used as a wake-up alarm, you also can set another two more alarms to be snooze function.
- All other alarms are 30 seconds long.
- The vibration can be stopped immediately by pressing any button.

- Alarms automatically repeat on schedule daily.
- When the Alarms goes off, vibrates with time flashing to remind.
- When the Timer goes off, vibrates only, totally discreet.

## Troubleshooting Guide

If the alarms don't vibrate:

- Press any button when the watch is charging to check the vibrator.
- Make sure the alarm is turned on.
- Check the watch is mute mode or vibrate mode.